

CHW 469 : Embedded Systems

Instructor:


Dr. Ahmed Shalaby

<http://bu.edu.eg/staff/ahmedshalaby14#>

AVR Programming in C

Chapter 7

The AVR microcontroller
and embedded
systems
using assembly and c



MUHAMMAD ALI MAZIDI
SARMAD NAIMI
SEPEHR NAIMI

Topics

- Data Types
- Time Delays
- IO Programming in C
- Logic Operation in C
- Data serialization in C

Data Types

- Use **unsigned** whenever you can
- **unsigned char** instead of **unsigned int** if you can

Table 7-1: Some Data Types Widely Used by C compilers

Data Type	Size in Bits	Data Range/Usage
unsigned char	8-bit	0 to 255
char	8-bit	-128 to +127
unsigned int	16-bit	0 to 65,535
int	16-bit	-32,768 to +32,767
unsigned long	32-bit	0 to 4,294,967,295
long	32-bit	-2,147,483,648 to +2,147,483,648
float	32-bit	$\pm 1.175e-38$ to $\pm 3.402e38$
double	32-bit	$\pm 1.175e-38$ to $\pm 3.402e38$

Time Delays in C

- You can use `for` to make time delay

```
void delay100ms(void){  
    unsigned int i ;  
    for (i=0; i<42150; i++);  
}
```

Time Delays in C


- You can use **for** to make time delay

```
void delay100ms(void){  
    unsigned int i ;  
    for(i=0; i<42150; i++);  
}
```

If you use for loop

- The clock frequency can change your delay duration !
- The compiler has direct effect on delay duration!
- You **MUST** set the optimization level to O0 !

How to set optimization level to O0



Time Delays in C

- You can use **pre defined** functions of compilers to make time delay

IN WinAVR :

First you should include:

```
#include <util/delay.h>
```

and then you can use

```
delay_ms(1000);  
delay_us(1000);
```

- It is compiler dependant not hardware dependant

Time Delays in C

- To overcome the portability problem, you can use macro or wrapper function. So to change the compiler you need to change only a simple function.

```
void delay_ms(int d)
{
    _delay_ms(d);
}
```

I/O programming in C

Byte size IO programming in C

```
DDRB = 0xFF;
while (1) {
    PORTB = 0xFF ;
    delay100ms () ;
    PORTB = 0x55 ;
    delay100ms () ;
}
```

I/O programming in C

Byte size IO programming in C

```
    DDRB = 0xFF;
    while (1) {
        PORTB = 0xFF ;
        delay100ms () ;
        PORTB = 0x55 ;
        delay100ms () ;
    }
```


Different compilers have different syntax for bit manipulations!

I/O programming in C

Byte size IO programming in C

```
DDRB = 0xFF;
while (1) {
    PORTB = 0xFF ;
    delay100ms () ;
    PORTB = 0x55 ;
    delay100ms () ;
}
```

Different compilers have different syntax for bit manipulations!



Masking is the best way

Logical Operations in C

1110 1111 && 0000 0001 = True AND True = True

1110 1111 || 0000 0000 = True OR False = True

!(1110 1111) = Not (True) = False

Bit-Wise logical operators

Table 7-3: Bit-wise Logic Operators for C

		AND	OR	EX-OR	Inverter
A	B	A&B	A B	A^B	Y=~B
0	0	0	0	0	1
0	1	0	1	1	0
1	0	0	1	1	0
1	1	1	1	0	1

1110 1111	1110 1111	
& 0000 0001	0000 0001	~ 1110 1011
-----	-----	-----
0000 0001	1110 1111	0001 0100

Shift operations in C

- `data >> number of bits to be shifted right`
- `data << number of bits to be shifted left`

1110 0000 >> 3

0001 1100

0000 0001 <<2

0000 0100

Setting a bit in a Byte to 1

- We can use `|` operator to set a bit of a byte to 1

XXXX XXXX		XXXX XXXX
0001 0000	OR	1 << 4
-----		-----
xxx1 xxxx		xxx1 xxxx

```
PORTB |= ( 1 << 4); //Set bit 4 (5th bit) of PORTB
```


Clearing a bit in a Byte to 0

- We can use & operator to clear a bit of a byte to 0

	XXXX XXXX		XXXX XXXX
&	1110 1111	OR	& ~(1 << 4)
	-----		-----
	xxx0 xxxx		xxx0 xxxx

```
PORTB &= ~( 1 << 4); //Clear bit 4 (5th bit) of PORTB
```

See Example 7-18

Checking a bit in a Byte

- We can use & operator to see if a bit in a byte is 1 or 0

	XXXX XXXX		XXXX XXXX
&	0001 0000	OR	& (1 << 4)
	-----		-----
	000x 0000		000x 0000

```
if (PINC & (1 << 5)) // check bit 5 (6th bit) of PINC
```

Data Serialization in C

- Any of serial ports (USART, SPI, I2C, JTAG,...)
- Do it yourself !

Example 7-30

Write an AVR program to send out the value 44H serially one bit at a time via PORTC, pin 3. The LSB should go out first.

Solution:

```
#include <avr/io.h>
#define serPin 3

int main(void)
{
    unsigned char conbyte = 0x44;
    unsigned char regALSB;
    unsigned char x;
    regALSB = conbyte;
    DDRC |= (1<<serPin) ;


    for(x=0;x<8;x++)
    {
        if( regALSB & 0x01)
            PORTC |= (1<<serPin);
        else
            PORTC &= ~(1<<serPin);
        regALSB = regALSB >> 1;
    }
    return 0;
}
```

Memory Types In AVR


- Flash Memory
 - Not deleted when power is off
 - Big in size
 - Suitable for codes, tables and fixed data
- EEPROM
 - Not deleted when power is off
 - Not very big in size
 - Suitable for small data that may be modified but should not be lost when power is off
- RAM
 - deleted when power is off
 - Suitable for storing the data we want to manipulate because we have fast access read or modify them.

AVR Hardware Connections and Flash Loading

The AVR microcontroller
and embedded
systems
using assembly and c




MUHAMMAD ALI MAZIDI
SARMAD NAIMI
SEPEHR NAIMI



Topics


- AVR Pins
- AVR simplest connections
- Fuse bits and clock source
- Fuse bits and startup time
- What is inside a hex file?
- Loading a hex file into flash
- Start with MDE AVR 32 Trainer board

ATmega 32 pins



ATmega 32 pins


PDIP



Clears all the registers and restart the execution of program

ATmega 32 pins


PDIP



Provides supply voltage to the chip. It should be connected to +5


ATmega 32 pins

PDIP




These pins are used to connect external crystal or RC oscillator

ATmega 32 pins




Reference voltage
for ADC

ATmega 32 pins



Supply voltage for
ADC and portA.
Connect it to VCC

AVR simplest connection



Fuse bytes of ATmega 32

Values of fuses is needed before system starts
They control some features of hardware
There are Fuse bytes in Atmega32

Fuse bytes of ATmega 32

Table 8-6 Fuse High Byte

Fuse High	Bit No.	Description	Default Value	Byte
OCDEN	7	Enable OCD	1 (unprogrammed)	
JTAGEN	6	Enable JTAG	0 (programmed)	
SPIEN	5	Enable SPI Serial Program and Data Downloading	0 (programmed)	
CKOPT	4	Oscillator options	1 (unprogrammed)	
EESAVE	3	EEPROM memory is preserved through the Chip Erase	1 (unprogrammed)	
BOOTSZ1	2	Select boot size	0 (programmed)	
BOOTSZ0	1	Select boot size	0 (programmed)	
BOOTRST	0	Select reset vector	1 (unprogrammed)	

Fuse bytes of ATmega 32

Table 8-7 Fuse Low Byte

Fuse High Byte	Bit No.	Description	Default Value
BODLEVEL	7	Brown-out Detector trigger level	1
BODEN	6	Brown-out Detector enable	1
SUT1	5	Select start-up time	1
SUT0	4	Select start-up time	0
CKSEL3	3	Select Clock source	0
CKSEL2	2	Select Clock source	0
CKSEL1	1	Select Clock source	0
CKSEL0	0	Select Clock source	1

Clock source in ATmega 32




Figure 8-4. Atmega32 Clock Sources

Clock source in ATmega 32




Figure 8-4. Atmega32 Clock Sources

Clock source in ATmega 32




Figure 8-5 External RC

Table 8-9 External RC Oscillator Operation Modes

CKSEL0..3	Frequency(MH)
0101	<0.9
0110	0.9- 3.0
0111	3.0- 8.0
1000	8.0- 12.0

clock Sources

Clock source in ATmega 32




Figure 8-6a. XTAL1-XTAL2 Connection to Crystal Oscillator

CKOPT	CKSEL3..1	Frequency (MH)
1	101	0.4 - 0.9
1	110	0.9 - 3.0
1	111	3.0 - 8.0
0	101, 110, 1111	1.0<

lock multiplex

nal C

Oscillator

Crystal Oscillator

Oscillator

lock Sources

Power on Reset and Burn on Detection

- Burn on Detection (BOD): Monitors the level of VCC and reset the system if ($VCC < \text{BOD level}$)
- The most difficult time for a system is during power up. To pass this time, In AVR when RESET pin becomes high, program does not starts running. It starts running after a specified time has elapsed. SUT0 and SUT1 define this time.

Power on Reset and Burn on Detection

Table 8-11: Startup time for crystal oscillator and recommended usage

CKSEL0	SUT1..0	Start-Up Time From Power Down	Delay From Reset(VCC=5)	Recommended Usage
0	00	258CK	4.1	Ceramic resonator, fast rising power
0	01	258CK	65	Ceramic resonator, slowly rising power
0	10	1K CK	-	Ceramic resonator, BOD enabled
0	11	1K CK	4.1	Ceramic resonator, fast rising power
1	00	1K CK	65	Ceramic resonator, slowly rising power
1	01	16K CK	-	Crystal Oscillator, BOD enabled
1	10	16K CK	4.1	Crystal Oscillator, fast rising power
1	11	16K CK	65	Crystal Oscillator, slowly rising power

Golden Rule of Fuse bits

If you are using an external crystal with a frequency more 1MH you can set all of the CKSEL3, CKSEL2, CKSEL1, SUT1 and SUT0 to 1 and clear CKOPT to 0.

Inside an HEX file

```
:0200000020000FC
:1000000008E00EBF0FE50DBF05E5009508BB0E9497
:100010000A00FBCF40E158EC6AEF000000006A954F
:0C002000E1F75A95C9F74A95B1F7089529
:00000001FF
```

Separating the fields, we get the following:

:BB	AAAA	TT	HHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHH	CC
:02	0000	02	0000	FC
:10	0000	00	08E00EBF0FE50DBF05E5009508BB0E94	97
:10	0010	00	0A00FBCF40E158EC6AEF000000006A95	4F
:0C	0020	00	E1F75A95C9F74A95B1F70895	29
:00	0000	01		FF

Figure 8-7. Intel Hex File Test Program with the Intel Hex Option

Inside an HEX file

```
:020000020000FC
:1000000008E00EBF0FE50DBF05E5009508BB0E9497
:100000000A00FBCF40E158EC6AEF000000006A954F
:0C00002000E1F75A95C9F74A95B1F7089529
:00000001
```

Each line starts
with a colon.

Separating the fields, we get the following:

```
:BB AAAA TT HHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHH CC
:02 0000 02 0000 FC
:10 0000 00 08E00EBF0FE50DBF05E5009508BB0E94 97
:10 0010 00 0A00FBCF40E158EC6AEF000000006A95 4F
:0C 0020 00 E1F75A95C9F74A95B1F70895 29
:00 0000 01 FF
```

Figure 8-7. Intel Hex File Test Program with the Intel Hex Option

Inside an HEX file

```
:020000020000FC
:100000000E9497
:100010000A954F
:0C002000E
:00000001E
```

This is a 16-bit address; The loader places the first byte of data into this memory address. It can address 64k locations

Separating the fields, we get the following:

```
:BB AAAA TT HHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHH CC
:02 0000 02 0000 FC
:10 0000 00 08E00EBF0FE50DBF05E5009508BB0E94 97
:10 0010 00 0A00FBCF40E158EC6AEF000000006A95 4F
:0C 0020 00 E1F75A95C9F74A95B1F70895 29
:00 0000 01 FF
```

Figure 8-7. Intel Hex File Test Program with the Intel Hex Option

Inside an HEX file

```
:020000020000FC
:1000000008E00E
:100010000A00FE
:0C002000E1F75A
:00000001FF
```

Type of line:
00: there are more lines to come after This line.
01: this is the last line
02: Segment address

Separating the fields, we get the following:

:BB	AAAA	TT	HH	CC
:02	0000	02	0000	FC
:10	0000	00	08E00EBF0FE50DBF05E5009508BB0E94	97
:10	0010	00	0A00FBCF40E158EC6AEF0000000006A95	4F
:0C	0020	00	E1F75A95C9F74A95B1F70895	29
:00	0000	01		FF

Figure 8-7. Intel Hex File Test Program with the Intel Hex Option

Inside an HEX file

```
:020000020000FC
:1000000008E00EBF0FE50DBF05E5009508BB0E9497
:100010000A00FBCF40E158EC6AEF000000006A954F
:0C002000E1F75A95C9F74A95B1F70895
:00000001FF
```



Real Data

Separating the fields, we get the following:

:BB	AAAA	TT	HHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHH	CC
:02	0000	02	0000	FC
:10	0000	00	08E00EBF0FE50DBF05E5009508BB0E94	97
:10	0010	00	0A00FBCF40E158EC6AEF000000006A95	4F
:0C	0020	00	E1F75A95C9F74A95B1F70895	29
:00	0000	01		FF

Figure 8-7. Intel Hex File Test Program with the Intel Hex Option

Inside an HEX file

```
:0200000020000FC  
:1000000008E00EBF0FE50DBF05E5009508BB0E9497  
:100010000A00FBCF40E158EC6AEF000000006A954F  
:0C002000E1F75A95C9F74A95B1F7089529  
:00000001FF
```

Checksum



Separating the fields, we get the following:

:BB	AAAA	TT	HHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHHH	CC
:02	0000	02	0000	FC
:10	0000	00	08E00EBF0FE50DBF05E5009508BB0E94	97
:10	0010	00	0A00FBCF40E158EC6AEF000000006A95	4F
:0C	0020	00	E1F75A95C9F74A95B1F70895	29
:00	0000	01		FF


Figure 8-7. Intel Hex File Test Program with the Intel Hex Option

AVR Programming


- Parallel programming
- ISP
 - SPI
 - JTAG
- Boot loader

Timer/counter

The AVR microcontroller
and embedded
systems
using assembly and c




A counter register




A simple design (counting people)

First design



A generic timer/counter

- Delay generating
- Counting
- Wave-form generating
- Capturing





Timers in AVR

- 1 to 6 timers
 - 3 timers in ATmega32
- 8-bit and 16-bit timers
 - two 8-bit timers and one 16-bit timer in ATmega32



Timer in AVR

- **TCNTn** (Timer/Counter register)
- **TOVn** (Timer Overflow flag)
- **TCCRn** (Timer Counter control register)
- **OCRn** (output compare register)
- **OCFn** (output compare match flag)



Timer in AVR

- TCNTn (Timer/Counter register)
- TOVn (Timer Overflow flag)
- TCCRn (Timer Counter control register)
- OCRn (output compare register)
- OCFn (output compare match flag)




Comment:



All of the timer registers are byte-addressable I/O registers


Timer 0 (an 8-bit timer)

The AVR microcontroller
and embedded
systems
using assembly and c




Timer 0







↑ ↑ ↑
Clock Selector (CS)

CS02	CS01	CS00	Comment
0	0	0	No clock source (Timer/Counter stopped)
0	0	1	clk (No Prescaling)
0	1	0	clk / 8
0	1	1	clk / 64
1	0	0	clk / 256
1	0	1	clk / 1024
1	1	0	External clock source on T0 pin. Clock on falling edge
1	1	1	External clock source on T0 pin. Clock on rising edge



CS02	CS01	CS00	Comment
0	0	0	No clock source (Timer/Counter stopped)
0	0	1	clk (No Prescaling)
0	1	0	clk / 8
0	1	1	clk / 64
1	0	0	clk / 256
1	0	1	clk / 1024
1	1	0	External clock source
1	1	1	External clock source







Timer Mode (WGM)



WGM00	WGM01	Comment
0	0	Normal
0	1	CTC (Clear Timer on Compare Match)
1	0	PWM, phase correct
1	1	Fast PWM

Normal mode



TOV0: 0

Normal mode



TOV0: 1



Example 1: Write a program that waits 14 machine cycles in Normal mode.

14 = \$0E

\$100

-\$0E

\$F2






Example 1: Write a program that waits 14 machine cycles in Normal mode.

14 = \$0E

\$100

-\$0E

\$F2





Example 1: Write a program that waits 14 machine cycles in Normal mode.

$$14 = \$0E$$


$$\$100$$

$$-\$0E$$

$$\$F2$$




WGM00	WGM01	Comment
0	0	Normal
0	1	CTC
1	0	PWM, phase correct
1	1	Fast PWM




Example 1: write a program that waits 14 machine cycles in Normal mode.

\$100



TCCR0

-\$0E



TIFR

\$F2

```
.INCLUDE "M32DEF.INC"
```

```
LDI R16,0x20
SBI DDRB,5 ;PB5 as an output
LDI R17,0
OUT PORTB,R17
BEGIN: LDI R20,0xF2
OUT TCNT0,R20 ;load timer0
LDI R20,0x01
OUT TCCR0,R20 ;Timer0,Normal mode,int clk
AGAIN: IN R20,TIFR ;read TIFR
SBRS R20,0 ;if TOV0 is set skip next inst.
RJMP AGAIN
LDI R20,0x0
OUT TCCR0,R20 ;stop Timer0
LDI R20,(1<<TOV0) ;R20 = 0x01
OUT TIFR,R20 ;clear TOV0 flag


EOR R17,R16 ;toggle D5 of R17
OUT PORTB,R17 ;toggle PB5
```

```
RJMP BEGIN
```

```
DDRB = 1<<5;
PORTB &= ~(1<<5); //PB5=0
while (1)
{
    TCNT0 = 0xF2;
    TCCR0 = 0x01;
    while((TIFR&(1<<TOV0))==0);
    TCCR0 = 0;
    TIFR = (1<<TOV0);
    PORTB = PORTB^(1<<5);
}
```


Example 1: write a program that waits 14 machine cycles in Normal mode.

\$100



TCCR0

-\$0E



TIFR

\$F2

```
.INCLUDE "M32DEF.INC"
```

```
LDI R16,0x20
SBI DDRB,5 ;PB5 as an output
LDI R17,0
OUT PORTB,R17
```

```
BEGIN: LDI R20,0xF2
OUT TCNT0,R20 ;load timer0
```

```
LDI R20,0x01
OUT TCCR0,R20 ;Ti
AGAIN: IN R20,TIFR
SBRS R20,0 ;if TOV
RJMP AGAIN
```

```
LDI R20,0x0
OUT TCCR0,R20
LDI R20,(1<<TOV0)
OUT TIFR,R20
```

```
EOR R17,R16
OUT PORTB,R17
```

```
RJMP BEGIN
```

```
DDRB = 1<<5;
PORTB &= ~(1<<5); //PB5=0
while (1)
{
```

Question: How to calculate the delay generated by the timer?

Answer:

- 1) Calculate how much a machine clock lasts.
 $T = 1/f$
- 2) Calculate how many machine clocks it waits.
- 3) Delay = $T * \text{number of machine cycles}$

In example 1 calculate the delay. Imagine XTAL = 10 MHz.

Solution 1 (inaccurate):

1) Calculating T:

$$T = 1/f = 1/10M = 0.1\mu s$$

2) Calculating num of machine cycles:

\$100

-\$F2

\$0E = 14

3) Calculating delay

$$14 * 0.1\mu s = 1.4 \mu s$$

```
.INCLUDE "M32DEF.INC"

        LDI    R16,0x20
        SBI    DDRB,5    ;PB5 as an output
        LDI    R17,0
        OUT    PORTB,R17

BEGIN:   LDI    R20,0xF2
        OUT    TCNT0,R20    ;load timer0
        LDI    R20,0x01
        OUT    TCCR0,R20    ;Timer0,Normal mode,int clk
AGAIN:   IN     R20,TIFR    ;read TIFR
        SBRS   R20,0    ;if TOV0 is set skip next inst.
        RJMP   AGAIN
        LDI    R20,0x0
        OUT    TCCR0,R20    ;stop Timer0
        LDI    R20,0x01
        OUT    TIFR,R20    ;clear TOV0 flag
        EOR    R17,R16    ;toggle D5 of R17
        OUT    PORTB,R17    ;toggle PB5
        RJMP   BEGIN
```

Accurate calculating

Other than timer, executing the instructions consumes time; so if we want to calculate the accurate delay a program causes we should add the delay caused by instructions to the delay caused by the timer

	LDI	R16,0x20	
	SBI	DDRB,5	
	LDI	R17,0	
	OUT	PORTB,R17	
BEGIN:	LDI	R20,0xF2	1
	OUT	TCNT0,R20	1
	LDI	R20,0x01	1
	OUT	TCCR0,R20	1
AGAIN:	IN	R20,TIFR	1
	SBRS	R20,0	1 / 2
	RJMP	AGAIN	2
	LDI	R20,0x0	1
	OUT	TCCR0,R20	1
	LDI	R20,0x01	1
	OUT	TIFR,R20	1
	EOR	R17,R16	1
	OUT	PORTB,R17	1
	RJMP	BEGIN	2
			18

Delay caused by timer = $14 * 0.1\mu\text{s} = 1.4 \mu\text{s}$

Delay caused by instructions = $18 * 0.1\mu\text{s} = 1.8$

Total delay = $3.2 \mu\text{s} \rightarrow$ wave period = $2 * 3.2 \mu\text{s} = 6.4 \mu\text{s} \rightarrow$ wave frequency = 156.25 KHz

Finding values to be loaded into the timer

1. Calculate the period of clock source.
 - Period = $1 / \text{Frequency}$
 - E.g. For XTAL = 8 MHz $\rightarrow T = 1/8\text{MHz}$
2. Divide the desired time delay by period of clock.
3. Perform $256 - n$, where n is the decimal value we got in Step 2.
4. Set $\text{TCNT0} = 256 - n$

Example 2: Assuming that XTAL = 10 MHz, write a program to generate a square wave with a period of 10 ms on pin PORTB.3.

- For a square wave with $T = 10 \mu\text{s}$ we must have a time delay of $5 \mu\text{s}$. Because $\text{XTAL} = 10 \text{ MHz}$, the counter counts up every $0.1 \mu\text{s}$. This means that we need $5 \mu\text{s} / 0.1 \mu\text{s} = 50$ clocks. $256 - 50 = 206$.

```
.INCLUDE "M32DEF.INC"
```

```
LDI R16,0x08
```

```
SBI DDRB,3 ;PB3 as an output
```

```
LDI R17,0
```

```
OUT PORTB,R17
```

```
BEGIN: LDI R20,206
```

```
OUT TCNT0,R20 ;load timer0
```

```
LDI R20,0x01
```

```
OUT TCCR0,R20 ;Timer0,Normal mode,int clk
```

```
AGAIN: IN R20,TIFR ;read TIFR
```

```
SBRS R20,TOV0 ;if TOV0 is set skip next
```

```
RJMP AGAIN
```

```
LDI R20,0x0
```

```
OUT TCCR0,R20 ;stop Timer0
```

```
LDI R20,0x01
```

```
OUT TIFR,R20 ;clear TOV0 flag
```

```
EOR R17,R16 ;toggle D3 of R17
```

```
OUT PORTB,R17 ;toggle PB3
```

```
RJMP BEGIN
```

```
DDRB = 1<<3;
```

```
PORTB &= ~ (1<<3);
```

```
while (1)
```

```
{
```

```
TCNT0 = 206;
```

```
TCCR0 = 0x01;
```

```
while((TIFR&0x01) == 0);
```

```
TCCR0 = 0;
```

```
TIFR = 1<<TOV0;
```

```
PORTB = PORTB ^ (1<<3);
```

```
}
```

Example 3: Modify TCNT0 in Example 2 to get the largest time delay possible with no prescaler. Find the delay in μs . In your calculation, do not include the overhead due to instructions.

- To get the largest delay we make TCNT0 zero. This will count up from 00 to 0xFF and then roll over to zero.

```
.INCLUDE "M32DEF.INC"

        LDI     R16,1<<3
        SBI     DDRB,3      ;PB3 as an output
        LDI     R17,0
        OUT     PORTB,R17
BEGIN:   LDI     R20,0x0
        OUT     TCNT0,R20      ;load Timer0
        LDI     R20,0x01
        OUT     TCCR0,R20 ;Timer0,Normal mode,int clk
AGAIN:   IN     R20,TIFR      ;read TIFR
        SBRS    R20,TOV0     ;if TOV0 is set skip next
        RJMP   AGAIN
        LDI     R20,0x0
        OUT     TCCR0,R20      ;stop Timer0
        LDI     R20,0x01
        OUT     TIFR,R20      ;clear TOV0 flag
        EOR     R17,R16      ;toggle D3 of R17
        OUT     PORTB,R17     ;toggle PB3
        RJMP   BEGIN
```

```
DDRB = 1 << 3;
PORTB &= ~(1<<3);

while (1)
{
    TCNT0 = 0x0;
    TCCR0 = 0x01;

while ((TIFR & (1<<TOV0)) == 0);

    TCCR0 = 0;
    TIFR = 0x01;
    PORTB = PORTB ^ (1<<3);
}
```


Example 3: Modify TCNT0 in Example 2 to get the largest time delay possible with no prescaler. Find the delay in μs . In your calculation, do not include the overhead due to instructions.

- To get the largest delay we make TCNT0 zero. This will count up from 00 to 0xFF and then roll over to zero.

```
.INCLUDE "M32DEF.INC"

        LDI     R16,1<<3
        SBI     DDRB,3      ;PB3 as an output
        LDI     R17,0
        OUT     PORTB,R17
BEGIN:   LDI     R20,0x0
        OUT     TCNT0,R20      ;load Timer0
        LDI     R20,0x01
        OUT     TCCR0,R20 ;Timer0,Normal mode,int clk
AGAIN:   IN      R20,TIFR
        SBRS    R20,TOV0
        RJMP   AGAIN
        LDI     R20,0x0
        OUT     TCCR0,R20
        LDI     R20,0x01
        OUT     TIFR,R20
        EOR     R17,R17
        OUT     PORTB,R17
        RJMP   BEGIN
```

```
DDRB = 1 << 3;
PORTB &= ~(1<<3);
while (1)
{
    TCNT0 = 0x0;
    TCCR0 = 0x01;

while ((TIFR & (1<<TOV0)) == 0);
    TCCR0 = 0;
    TIFR = 0x01;
    PORTB = PORTB ^ (1<<3);
}
```

Solution

1) Calculating T:

$$T = 1/f = 1/10\text{MHz} = 0.1\mu\text{s}$$


2) Calculating delay

$$256 * 0.1\mu\text{s} = 25.6\mu\text{s}$$



Generating Large Delays

- Using loop
- Prescaler
- Bigger counters

Prescaler and generating a large time delay




CTC (Clear Timer on Compare match) mode



TOV0: 0

OCF0: 1

Rewrite example 2 using CTC



- For a square wave with $T = 10 \mu\text{s}$ we must have a time delay of $5 \mu\text{s}$. Because $\text{XTAL} = 10 \text{ MHz}$, the counter counts up every $0.1 \mu\text{s}$. This means that we need $5 \mu\text{s} / 0.1 \mu\text{s} = 50$ clocks. Therefore, we have $\text{OCR0} = 49$.

```

.INCLUDE "M32DEF.INC"
    LDI    R16,0x08
    SBI    DDRB,3    ;PB3 as an output
    LDI    R17,0
    OUT    PORTB,R17
    LDI    R20,49
    OUT    OCR0,R20 ;load timer0
BEGIN:  LDI    R20,0x09
    OUT    TCCR0,R20 ;Timer0,CTC mode,int clk
AGAIN:  IN     R20,TIFR    ;read TIFR
    SBRS   R20,OCF0 ;if OCF0 is set skip next
    RJMP   AGAIN
    LDI    R20,0x0
    OUT    TCCR0,R20    ;stop Timer0
    LDI    R20,0x02
    OUT    TIFR,R20    ;clear TOV0 flag
    EOR    R17,R16    ;toggle D3 of R17
    OUT    PORTB,R17    ;toggle PB3
    RJMP   BEGIN

```

```

DDRB |= 1<<3;
PORTB &= ~(1<<3);
while (1)
{
    OCR0 = 49;
    TCCR0 = 0x09;


while((TIFR&(1<<OCF0))==0);

    TCCR0 = 0; //stop timer0
    TIFR = 0x02;
    PORTB.3 = ~PORTB.3;
}



```

Timer2

■ Timer0



■ Timer2



The difference between Timer0 and Timer2



■ Timer0


CS02	CS01	CS00	Comment
0	0	0	Timer/Counter stopped
0	0	1	clk (No Prescaling)
0	1	0	clk / 8
0	1	1	clk / 64
1	0	0	clk / 256
1	0	1	clk / 1024
1	1	0	External clock (falling edge)
1	1	1	External clock (rising edge)

■ Timer2


CS22	CS21	CS20	Comment
0	0	0	Timer/Counter stopped
0	0	1	clk (No Prescaling)
0	1	0	clk / 8
0	1	1	clk / 32
1	0	0	clk / 64
1	0	1	clk / 128
1	1	0	clk / 256
1	1	1	clk / 1024

Timer 1






CS12	CS11	CS10	Comment
0	0	0	No clock source (Timer/Counter stopped)
0	0	1	clk (No Prescaling)
0	1	0	clk / 8
0	1	1	clk / 64
1	0	0	clk / 256
1	0	1	clk / 1024
1	1	0	External clock source on T0 pin. Clock on falling edge
1	1	1	External clock source on T0 pin. Clock on rising edge




Clock Selector (CS)

CS12 CS11 CS10 | Comment


0	0	0	No clock
0	0	1	clk (No P
0	1	0	clk / 8
0	1	1	clk / 64
1	0	0	clk / 256
1	0	1	clk / 1024
1	1	0	External
1	1	1	External





CS12 CS11 CS10 | Comment

0	0	0	No clock source (Timer/Counter stopped)
0	0	1	clk (No Prescaling)
0	1	0	clk / 8
0	1	1	clk / 64
1	0	0	clk / 256
1	0	1	clk / 1024
1	1	0	External clock source on T0 pin. Clock on falling edge
1	1	1	External clock source on T0 pin. Clock on rising edge




Mode	WGM13	WGM12 (CTC1)	WGM11 (PWM11)	WGM10 (PWM10)	Timer/Counter Mode of Operation	TOP	Update of OCR1x	TOV1 Flag Set on
0	0	0	0	0	Normal	0xFFFF	Immediate	MAX
1	0	0	0	1	PWM, Phase Correct, 8-bit	0x00FF	TOP	BOTTOM
2	0	0	1	0	PWM, Phase Correct, 9-bit	0x01FF	TOP	BOTTOM
3	0	0	1	1	PWM, Phase Correct, 10-bit	0x03FF	TOP	BOTTOM
4	0	1	0	0	CTC	OCR1A	Immediate	MAX
5	0	1	0	1	Fast PWM, 8-bit	0x00FF	TOP	TOP
6	0	1	1	0	Fast PWM, 9-bit	0x01FF	TOP	TOP
7	0	1	1	1	Fast PWM, 10-bit	0x03FF	TOP	TOP
8	1	0	0	0	PWM, Phase and Frequency Correct	ICR1	BOTTOM	BOTTOM
9	1	0	0	1	PWM, Phase and Frequency Correct	OCR1A	BOTTOM	BOTTOM
10	1	0	1	0	PWM, Phase Correct	ICR1	TOP	BOTTOM
11	1	0	1	1	PWM, Phase Correct	OCR1A	TOP	BOTTOM
12	1	1	0	0	CTC	ICR1	Immediate	MAX
13	1	1	0	1	Reserved	-	-	-
14	1	1	1	0	Fast PWM	ICR1	TOP	TOP
15	1	1	1	1	Fast PWM	OCR1A	TOP	TOP

Assuming XTAL = 10 MHz write a program that toggles PB5 once per millisecond, using Normal mode.

XTAL = 10 MHz \rightarrow $1/10$ MHz = $0.1 \mu\text{s}$

Num. of machine cycles = $1 \text{ ms} / 0.1 \mu\text{s} = 10,000$

TCNT1 = $65,536 - 10,000 = 55,536 = \$D8F0$



Assuming XTAL = 10 MHz write a program that toggles PB5 once per millisecond, using Normal mode.

```
.INCLUDE "M32DEF.INC"
    LDI    R16,HIGH(RAMEND)    ;init stack pointer
    OUT    SPH,R16
    LDI    R16,LOW(RAMEND)
    OUT    SPL,R16
    SBI    DDRB,5              ;PB5 as an output
BEGIN:SBI PORTB,5              ;PB5 = 1
    RCALL  DELAY_1ms
    CBI    PORTB,5              ;PB5 = 0
    RCALL  DELAY_1ms
    RJMP   BEGIN


DELAY_1ms:
    LDI    R20,0xD8
    OUT    TCNT1H,R20          ;TEMP = 0xD8
    LDI    R20,0xF0
    OUT    TCNT1L,R20          ;TCNT1L = 0xF0, TCNT1H = TEMP
    LDI    R20,0x0
    OUT    TCCR1A,R20          ;WGM11:10=00
    LDI    R20,0x1
    OUT    TCCR1B,R20          ;WGM13:12=00,CS=CLK
AGAIN:IN  R20,TIFR              ;read TIFR
    SBRS   R20,TOV1            ;if OCF1A is set skip next instruction
    RJMP   AGAIN
    LDI    R20,1<<TOV1
    OUT    TIFR,R20            ;clear TOV1 flag
    LDI    R19,0
    OUT    TCCR1B,R19          ;stop timer
    OUT    TCCR1A,R19          ;
    RET
```

Assuming XTAL = 10 MHz write a program that toggles PB5 once per millisecond, using Normal mode.

```
.INCLUDE "M32DEF.INC"
    LDI    R16,HIGH(RAMEND)    ;init stack pointer
    OUT    SPH,R16
    LDI    R16,LOW(RAMEND)
    OUT    SPL,R16
    SBI    DDRB,5              ;PB5 as an output
BEGIN:SBI PORTB,5              ;PB5 = 1
    RCALL  DELAY_1ms
    CBI    PORTB,5              ;PB5 = 0
    RCALL  DELAY_1ms
    RJMP  BEGIN

DELAY_1ms:
    LDI    R20,HIGH(-10000)
    OUT    TCNT1H,R20
    LDI    R20,LOW(-10000)
    OUT    TCNT1L,R20          ;Timer1 overflows after 10000 machine cycles
    LDI    R20,0x0
    OUT    TCCR1A,R20          ;WGM11:10=00
    LDI    R20,0x1
    OUT    TCCR1B,R20          ;WGM13:12=00,CS=CLK
AGAIN:IN  R20,TIFR              ;read TIFR
    SBRS  R20,TOV1              ;if OCF1A is set skip next instruction
    RJMP  AGAIN
    LDI    R20,1<<TOV1
    OUT    TIFR,R20            ;clear TOV1 flag
    LDI    R19,0
    OUT    TCCR1B,R19          ;stop timer
    OUT    TCCR1A,R19          ;
    RET
```

TEMP register




Note: OCR1x is OCR1A or OCR1B

```
LDI R20, 0xF3
OUT TCNT1H, R20
LDI R20, 0x53
OUT TCNT1L, R20
```

```
TCNT1H = 0xF3;
TCNT1L = 0x53;
```


TEMP register



Note: OCR1x is OCR1A or OCR1B

```
IN R20, TCNT1L
IN R21, TCNT1H
```

```
a = TCNT1L;
b = TCNT1H;
```

Assuming XTAL = 10 MHz write a program that toggles PB5 once per millisecond, using CTC mode.

```
.INCLUDE "M32DEF.INC"
    LDI    R16,HIGH(RAMEND)
    OUT    SPH,R16
    LDI    R16,LOW(RAMEND)
    OUT    SPL,R16
    SBI    DDRB,5                ;PB5 as an output
BEGIN:SBI    PORTB,5            ;PB5 = 1
    RCALL  DELAY_1ms
    CBI    PORTB,5            ;PB5 = 0
    RCALL  DELAY_1ms
    RJMP   BEGIN

DELAY_1ms:
    LDI    R20,0x00
    OUT    TCNT1H,R20          ;TEMP = 0
    OUT    TCNT1L,R20          ;TCNT1L = 0, TCNT1H = TEMP

    LDI    R20,0x27
    OUT    OCR1AH,R20          ;TEMP = 0x27
    LDI    R20,0x0F
    OUT    OCR1AL,R20          ;OCR1AL = 0x0F, OCR1AH = TEMP


    LDI    R20,0x3
    OUT    TCCR1A,R20          ;WGM11:10=11
    LDI    R20,0x19
    OUT    TCCR1B,R20          ;WGM13:12=11,CS=CLK

AGAIN:
    IN     R20,TIFR            ;read TIFR
    SBRS  R20,OCF1A           ;if OCF1A is set skip next instruction
    RJMP  AGAIN
    LDI    R20,1<<OCF1A
    OUT    TIFR,R20            ;clear OCF1A flag
    LDI    R19,0
    OUT    TCCR1B,R19          ;stop timer
    OUT    TCCR1A,R19          ;
    RET
```



Counting

The AVR microcontroller
and embedded
systems
using assembly and c

MUHAMMAD ALI MAZIDI
SARMAD NAIMI
SEPEHR NAIMI





Counting



(XCK/T0) PB0	1	40	PA0 (ADC0)
(T1) PB1	2	39	PA1 (ADC1)
(INT2/AIN0) PB2	3	38	PA2 (ADC2)
(OC0/AIN1) PB3	4	37	PA3 (ADC3)
(\overline{SS}) PB4	5	36	PA4 (ADC4)
(MOSI) PB5	6	35	PA5 (ADC5)
(MISO) PB6	7	34	PA6 (ADC6)
(SCK) PB7	8	33	PA7 (ADC7)
RESET	9	32	AREF
VCC	10	31	GND
GND	11	30	AVCC
XTAL2	12	29	PC7 (TOSC2)
XTAL1	13	28	PC6 (TOSC1)
(RXD) PD0	14	27	PC5 (TDI)
(TXD) PD1	15	26	PC4 (TDO)
(INT0) PD2	16	25	PC3 (TMS)
(INT1) PD3	17	24	PC2 (TCK)
(OC1B) PD4	18	23	PC1 (SDA)
(OC1A) PD5	19	22	PC0 (SCL)
(ICP) PD6	20	21	PD7 (OC2)


Counting



(XCK/T0) PB0	1	40	PA0 (ADC0)
(T1) PB1	2	39	PA1 (ADC1)
(INT2/AIN0) PB2	3	38	PA2 (ADC2)
(OC0/AIN1) PB3	4	37	PA3 (ADC3)
(SS) PB4	5	36	PA4 (ADC4)
(MOSI) PB5	6	35	PA5 (ADC5)
(MISO) PB6	7	34	PA6 (ADC6)
(SCK) PB7	8	33	PA7 (ADC7)
RESET	9	32	AREF
VCC	10	31	GND
GND	11	30	AVCC
XTAL2	12	29	PC7 (TOSC2)
XTAL1	13	28	PC6 (TOSC1)
(RXD) PD0	14	27	PC5 (TDI)
(TXD) PD1	15	26	PC4 (TDO)
(INT0) PD2	16	25	PC3 (TMS)
(INT1) PD3	17	24	PC2 (TCK)
(OC1B) PD4	18	23	PC1 (SDA)
(OC1A) PD5	19	22	PC0 (SCL)
(ICP) PD6	20	21	PD7 (OC2)

Example Assuming that clock pulses are fed into pin T0, write a program for counter 0 in normal mode to count the pulses on falling edge and display the state of the TCNT0 count on PORTC.

```
.INCLUDE "M32DEF.INC"
    CBI  DDRB,0           ;make T0 (PB0) input
    LDI  R20,0xFF
    OUT  DDRC,R20        ;make PORTC output
    LDI  R20,0x06
    OUT  TCCR0,R20       ;counter, falling edge
AGAIN:
    IN   R20,TCNT0
    OUT  PORTC,R20       ;PORTC = TCNT0
    IN   R16,TIFR
    SBRS R16,TOV0
    RJMP AGAIN           ;keep doing it
    LDI  R16,1<<TOV0
    OUT  TIFR, R16
    RJMP AGAIN           ;keep doing it
```





Example Assuming that clock pulses are fed into pin T0, write a program for counter 0 in normal mode to count the pulses on falling edge and display the state of the TCNT0 count on PORTC.

```

.INCLUDE "M32DEF.INC"

CBI  DDRB,0           ;make T0 (PB0) input
LDI  R20,0xFF        ;make PORTC output
OUT  DDRC,R20
LDI  R20,0x06        ;counter, falling edge
OUT  TCCR0,R20

AGAIN:
IN   R20,TCNT0       ;PORTC = TCNT0
OUT  PORTC,R20
IN   R16,TIFR
SBRS R16,TOV0        ;keep doing it
RJMP AGAIN
LDI  R16,1<<TOV0
OUT  TIFR, R16
RJMP AGAIN           ;keep doing it
    
```



TCCR0

Assuming that clock pulses are fed into pin T1. Write a program for counter 1 in CTC mode to make PORTC.0 high every 100 pulses.

```
.INCLUDE "M32DEF.INC"

CBI  DDRB,1           ;make T1 (PB1) input

SBI  DDRC,0           ;PC0 as an output

LDI  R20,0x0
OUT  TCCR1A,R20
LDI  R20,0x0E
OUT  TCCR1B,R20       ;CTC, counter, falling edge
AGAIN:
LDI  R20,0
OUT  OCR1AH,R20       ;TEMP = 0
LDI  R20,99
OUT  OCR1AL,R20       ;ORC1L = R20, OCR1H = TEMP
L1:  IN  R20,TIFR
SBR  R20,OCF1A
RJMP L1               ;keep doing it
LDI  R20,1<<OCF1A    ;clear OCF1A flag
OUT  TIFR, R20

SBI  PORTC,0         ;PC0 = 1
CBI  PORTC,0         ;PC0 = 0
RJMP AGAIN           ;keep doing it
```